

INDEX

A			B		
Subject	Para- graph	Page	Subject	Para- graph	Page
AC Outlets	5-6d(1)	5-36	Balancing Tire and Wheel	4-24e	4-25
AC to DC Converter	5-6c(1)	5-33	Bathroom (Also See Specific Item Entry)	5-3	5-13
Acceleration for Passing	5-6d(5)	5-38	Batteries, Domestic:		
Accelerator Pedal	4-14	4-14	Description	5-6c(2)	5-35
Accumulator, Water System ..	4-9z	4-10	Maintenance	5-6c(4)	5-35
Adjusting Brakes:	5-5e(2)	5-27	Test Switch	5-6b(6)	5-33
Parking Brakes	4-30e	4-39	Warranty	5-6c(5)	5-36
Service Brakes	4-30d	4-38	Battery, Automotive	4-18b	4-15
Adjusting Furnace Main Burner	5-4a(4)(b)	5-19	Battery Care	4-25b	4-26
Adjusting Furnace Pilot Light	5-4a(4)(a)	5-19	Battery Data	6-4	6-2
Adjusting Water Heater Main Burner	5-5h	5-29	Beds	5-2c	5-10
Adjusting Water Heater Pilot Light	5-5g	5-29	Before Starting Checklist	4-10	4-10
Air Conditioner Service Compartment	4-51	4-5	Body Maintenance	4-31	4-39
Air Conditioning and Heating Controls	4-9o	4-8	Books, Helpful	7-5	7-14
Air Conditioning Data	6-13	6-4	Brake Data	6-7	6-3
Air Conditioning System, Automotive:			Break-in	4-2	4-1
Data	6-13	6-4	Brake Indicator.....	4-9j	4-7
Description	4-20	4-21	Brake Lever, Parking	4-9q	4-8
Operation:			Brake Pedal	4-9y	4-10
Front Unit	4-22	4-23	Brake System:		
Rear Unit	4-23	4-23	Adjustment:		
Air Conditioning System, Domestic:			Brake Shoe	4-30d	4-38
Data	6-13	6-4	Parking Brake	4-30e	4-39
Description	5-4b	5-19	Bleeding	4-30c	4-38
Maintenance	5-4b(2)	5-21	Data	6-7	6-3
Operation	5-4b(1)	5-20	Parking	4-30b	4-38
Air in Coach (Also See Specific Item Entry)	5-4	5-16	Service	4-30a	4-38
Aligning Wheels	4-24f	4-26	Bumpers	4-6	4-5
Alternator Care	4-25e	4-31			
Alternator Indicator.....	4-9g	4-7	C		
Automotive Air Conditioning:			Camping Suggestions	7-1	7-1
Data	6-13	6-4	Campsite Drainage	5-8b	5-47
System	4-20	4-21	Capacities	6-3	6-1
Automotive Battery	4-18b	4-15	Carburetor Adjustment.....	4-26a	4-31
Automotive Battery Data	6-4	6-2	Ceiling Vents	5-2f	5-13
Automotive Electrical Data ...	6-11	6-3	Central Air Conditioner Service Compartment	4-51	4-5
Automotive Heating System ...	4-20	4-21	Central Heating (Also See Furnace).....	5-4a	5-16
Auxiliary Power Unit:			Certificate of Warranty	2-2c	2-2
Compartment.....	4-5f/g	4-3	Clean Air Emission System:		
Description	5-6e(1)	5-38	Federal Act	4-27a	4-32
Maintenance	5-6e(3)	5-39	Gasoline Improvements	4-27f	4-35
Operation	5-6e(2)	5-38	Maintenance:		
Switch	5-6b(10)	5-33	Source and Evidence	4-27c	4-33
Appliance Warranty Registration.....	2-3	2-2	Services Table		4-35
			Normal Coach Use	4-27b	4-32
			Positive Crankcase Ventilation:		
			Description	4-27g	4-35
			Operation	4-27h	4-36
			Replacement Parts	4-27d	4-34
			Source of Emissions	4-27e	4-35

C (Continued)

Subject	Para-graph	Page
Cleaning Coach Body	4-31a	4-39
Clearance/Identification		
Lights	4-19g	4-15
Closet	5-2e	5-12
Changing a Wheel	4-24c	4-24
Chart for Periodic Maintenance/Lubrication Services		4-27
Checklists		
Before Starting	4-10	4-10
Equipment	7-2	7-7
Food	7-2	7-6
Tools	7-2	7-8
City Water Connection	5-5c	5-24
City Water Connection Compartment	4-5b	4-3
Circuit Breakers	5-6d(2)	5-36
Coach Body Maintenance	4-31	4-39
Coach Living		5-1
Coach Serial Number Plate	4-1a	4-1
Controls and Instruments, Driver (Also See Specific Item Entry)	4-9	4-6
Cooling System:		
Description	4-29	4-36
Fan Belt Tension	4-29a	4-36
Fill and Drain	4-29d	4-37
Hoses and Connections	4-29b	4-36
Thermostat	4-29c	4-37

D

Data and Specifications		6-1
Dealers		3-1
Defroster Operation	4-21	4-23
Differential Data	6-10	6-3
Dimensions	6-1	6-1
Dinette (Also See Specific Item Entry)	5-2a	5-10
Directory of Service		3-1
Domestic Air Conditioning		
Data	6-13	6-5
Domestic Battery Data	6-4	6-2
Domestic Electrical Data	6-12	6-4
Domestic Equipment Data	6-14	6-5
Domestic Panel (Also See Specific Item Entry)	5-6b	5-32
Drainage System:		
Campsite Drainage	5-8b	5-47
Description	5-8a	5-46
Disposal Stations	5-8c	5-47
Drain Control Valves	5-8e	5-47
Drainage Hole	5-8f	5-48
Holding Tanks	5-8d	5-47
Maintenance	5-8h	5-50
Waste Destruct	5-8g	5-49
Draining Cooling System	4-29d	4-37
Driver's Instruments and Controls (Also See		

D (Continued)

Subject	Para-graph	Page
Specific Item Entry)	4-9	4-6
Driver's/Passenger Windows	4-9w	4-9
Driver's Seat	4-8a	4-5
Driving Hints	7-3	7-8
Dusty Operating Conditions ...	4-25d	4-31

E

Electric Ignition of Furnace... ..	5-4a(2)	5-16
Electrical System, Domestic (Also See Specific Item Entry)	5-6	5-29
Electrical Systems (Also See Specific Item Entry)	4-18	4-14
Electrical Data:		
Automotive	6-11	6-3
Domestic	6-12	6-4
Emission Control Maintenance Services		4-35
Engine:		
Data	6-6	6-2
Identification Plate	4-1b	4-1
Ignition	4-18a	4-15
Oil Pressure Gauge	4-9d	4-6
Service Compartment	4-5i	4-3
Starting	4-11	4-13
Stopped Indicator	4-9k	4-7
Tune-up	4-28	4-36
Engine, Transmission, and APU Service Compartment	4-5g	4-3
Engine Emission Certification Decal	4-1c	4-1
Environmental Air (Also See Specific Item Entry)	5-4	5-16
Exterior Body:		
Care and Cleaning	4-31a	4-39
Maintenance	4-31b	4-40
Exterior Compartments (Also See Specific Item Entry) ...	4-5	4-3
External Power Source (Also See Specific Item Entry) ...	5-6d	5-36

F

Fan Belt Tension	4-29a	4-36
Faucets	5-5e(3)	5-27
Federal Clean Air Act	4-27a	4-32
Filling Cooling System	4-29d	4-37
Filter, Water System	5-5e(4)	5-28
Fire Extinguisher	5-9	5-50
Fire Permits	7-1j	7-5
FMC Warranty	2-1	2-1
Folding Door	5-2d	5-12
Fresh Water Fill Compartment	4-5a	4-3
Fresh Water System:		
Adjustment:		
Pilot Light	5-5g	5-29
Main Burner	5-5h	5-29

F (Continued)

Subject	Para-graph	Page
City Water Connection.....	5-5c	5-24
Description	5-5a	5-21
Lighting Heater	5-5f	5-28
Maintenance:		
Components	5-5e	5-26
System	5-5d	5-24
Operation	5-5b	5-23
Fuel Filter Change	4-26b	4-31
Fuel Gauge	4-9e	4-6
Fuel System (Also See Specific Item Entry).....	4-26	4-31
Fuel Tank Fill Compartment..	4-5e	4-3
Furnace:		
Adjustment:		
Pilot Light	5-4a(4)(a)	5-19
Main Burner	5-4a(4)(b)	5-19
Description	5-4a	5-16
Ignition, Electric	5-4a(2)	5-16
Maintenance	5-4a(4)	5-19
Operation	5-4a(3)	5-18
Preliminary Procedures ...	5-4a(1)	5-16
Turn Off	5-4a(5)	5-19
Fuse Panel	5-6c(3)	5-35
Fuses	4-18d	4-15

G

Generator Switch	5-6b(10)	5-33
------------------	----------	------

H

Hazard Switch	4-9m	4-8
Headlights	4-19a	4-15
Heater/Air Conditioning		
Controls	4-9o	4-8
Heater Defroster Operation...	4-21	4-23
Heater, Water System:		
Adjustment:		
Pilot Light	5-5g	5-29
Main Burner	5-5h	5-29
Description	5-5e(6)	5-28
Lighting	5-5f	5-28
Heating Service Compartment.	4-5c	4-3
Heating Systems:		
Automotive	4-20	4-21
Central	5-4	5-16
High Beam:		
Foot Switch	4-19b	4-15
Indicator	4-9i	4-7
Holding on Upgrade	4-15	4-14
Holding Tanks:		
No. 1 Switch	5-6b(4)	5-32
No. 2 Switch	5-6b(5)	5-32
Hot Line Service		i

I

Subject	Para-graph	Page
Identification/Clearance		
Lights	4-19g	4-15
Identification Plates (Also See Specific Item Entry) ...	4-1	4-1
Ignition	4-18a	4-15
Ignition Switch	4-18c	4-15
Igniting Furnace	5-4a(2)	5-16
Illustrations	1-2	1-1
Instruments and Controls, Driver (Also See Specific Item Entry).....	4-9	4-6
Internal Power Source (Also See Specific Item Entry) ...	5-6c	5-33
Introduction		1-1

J

Jacking Coach	4-24b	4-24
---------------------	-------	------

K

Keys	4-3	4-3
Kitchen (Also See Specific Item Entry)	5-1	5-1

L

License Plate Light	4-19e	4-15
Lighting Water Heater.....	5-5f	5-28
Lights (Also See Specific Light Entry)	4-19	4-15
Lights Switch	4-9n	4-8
Living in Coach.....		5-1
Liquid Petroleum Gas System:		
Description:		
System	5-7a	5-43
LPG	5-7b	5-43
Gas Level Meter	5-7j	5-45
Gas Supply Lines	5-7i	5-45
Maintenance	5-7l	5-45
Refilling	5-7k	5-45
Regulator	5-7h	5-44
Storage Tank	5-7c	5-43
Valves:		
Safety Relief.....	5-7d	5-44
Fill.....	5-7e	5-44
Outage	5-7f	5-44
Main/Service Outlet	5-7g	5-44
LP Gas Service Compart- ment	4-5k	4-5

L (Continued)

Subject	Para- graph	Page
Lock Coach	4-4	4-3
Lubrication:		
Chart		4-27
Notes		4-29
Lubrication and Maintenance (Also See Specific Item Entry)	4-25	4-26

M

Main Burner Adjustment:		
Furnace	5-4a(4)(b)	5-19
Water Heater	5-5h	5-29
Maintenance and Lubrication (Also See Specific Item Entry)	4-25	4-26
Manual Sections:	1-1	1-1
Data		6-1
Introduction		1-1
Living		5-1
Operation		4-1
Service		3-1
Travel Aids		7-1
Warranty		2-1
Map Lights	4-9v	4-9
Microwave Oven (Optional Equipment):		
Description	5-1b(2)	5-4
General	5-1b(1)	5-4
How to Cook with Microwave	5-1b(4)	5-4
Name Plate	5-1b(5)	5-7
Safety Features	5-1b(3)	5-4
Mirrors	4-9u	4-9

N

National Highway Traffic Safety Plate	4-1d	4-1
Non Warranted Items and Services	2-5	2-2
Notes on Periodic Maintenance/ Lubrication Services		4-29

O

Off-Road Cooling System (Also See Air Conditioning, Domestic):		
Description	5-4b	5-19
Maintenance	5-4b(2)	5-21
Operation	5-4b(1)	5-20
110-Volt Service Line Compartment	4-5f	4-3
Operating Coach		4-1

O (Continued)

Subject	Para- graph	Page
Oven/Range:		
Description	5-1a	5-1
Maintenance and Cleaning ..	5-1a(3)	5-3
Operation	5-1a(2)	5-2
Preliminary Procedures ...	5-1a(1)	5-1
Owner's Emission Control Services		4-35
Owner's Registration Card ...	2-2b	2-2

P

Packing Supplies	7-1e	7-4
Park/Turn Signal Light	4-19c	4-15
Parking Brake:		
Adjustment	4-30e	4-39
Data	6-7	6-3
Lever	4-9q	4-8
Passenger:		
Door Step	4-8c	4-6
Seat	4-8b	4-6
Passenger/Driver's Windows .	4-9w	4-9
Passing Acceleration	4-14	4-14
Periodic Maintenance/ Lubrication Services:		
Chart		4-27
Notes		4-29
Pilot Light Adjustment:		
Furnace	5-4a(4)(b)	5-19
Water Heater	5-5g	5-29
Plumbing Service Compart- ment	4-5c	4-3
Positive Crankcase Ventila- tion:		
Description	4-27g	4-35
Operation	4-27h	4-36
Power Control Relay	5-6d(3)	5-37
Power Steering Pump	4-25f	4-31
Preface		i
Propeller Shaft Data	6-9	6-3
Purifier, Water System	5-5e(5)	5-28
Purifying Water System	5-5d(3)	5-25

R

Radiator Fill Compartment ...	4-5h	4-3
Radio Controls	5-6b(1)	5-32
Range/Oven	5-1a	5-1
Range Selector	4-9p	4-8
Rear Compartment (Also See Specific Item Entry)	5-2c	5-10
Rear Lights	4-19d	4-15
Recreational Vehicle Emblem .	4-1g	4-1
Refilling LPG System	5-7k	5-45
Refrigerator:		
Description	5-1c	5-7

R (Continued)

Subject	Para- graph	Page
Maintenance and Cleaning ..	5-1c(2)	5-8
Operation	5-1c(1)	5-8
Troubleshooting	5-1c(2)	5-9
Refueling	4-16	4-14
Registration Cards:		
Owner's	2-2b	2-2
Subsequent Owner	2-2d	2-2
Registration of Appliance		
Warranty	2-3	2-2
Registration of Warranty	2-2	2-1
Repair Policy	2-6	2-3
Reservations	7-1d	7-4
Right Side Storage Compart- ment	4-5m	4-5
Rocking Coach	4-13	4-14
Rotating Tires	4-24d	4-25
Running Lights	4-19f	4-15

S

Scratch Removal	4-31b	4-40
Seat Belts	4-9x	4-10
Service and Repair Policy	2-6	2-3
Service Brake:		
Adjustment	4-30d	4-38
Data	6-7	6-3
Service Centers:		
Dodge RVD	3-7	3-7
FMC/Union Oil	3-4	3-4
Service Directory	3-1	3-1
Service Hot Line		
Service Power Line	5-6d(4)	5-37
Severe Operating Conditions ..	4-25c	4-31
Shifting Transmission	4-12	4-13
Shower	5-3b	5-13
Sinks in Kitchen	5-1d	5-9
Ski Storage Compartment	4-5j	4-3
Spare Tire and Wheel	4-24a	4-23
Specifications and Data	6-1	6-1
Speed Limits	7-4a	7-12
Speedometer	4-9b	4-6
Starting Engine:		
Assist Starting	4-11e	4-13
Extremely Cold Weather		
Starting	4-11c	4-13
Flooded Engine Starting ..	4-11d	4-13
Normal Starting -		
Engine Cold	4-11a	4-13
Normal Starting -		
Engine Warm	4-11b	4-13
Starting - Ignition Switch ...	4-9a	4-6
State Identification Plate	4-1e	4-1
State Laws	7-4	7-12

S (Continued)

Subject	Para- graph	Page
Steering Wheel	4-9r	4-9
Storage Compartment, Right Side	4-5m	4-5
Subsequent Owner's Registra- tion Card	2-2d	2-2
Sun Visors	4-9t	4-9
Supplier-Warranted Items	2-4	2-2

T

Tachometer	4-9c	4-6
Tank Test Indicators	5-6b(2)	5-32
Thermostat	4-29c	4-37
Tire and Rim Plate	4-1f	4-1
Tire and Wheel Balance	4-24e	4-25
Tires and Wheels (Also See ' Specific Item Entry)	4-24	4-23
Tire Rotation	4-24d	4-25
Toilet:		
Cleaning	5-3c(2)	5-15
Description	5-3c	5-14
Operation	5-3c(1)	5-14
Storage	5-3c(3)	5-15
Troubleshooting	5-3c(4)	5-15
Towing	4-17	4-14
Trailer Electrical Connector .	4-7	4-5
Transmission:		
Data	6-8	6-3
Range Selector	4-9p	4-8
Shifting	4-12	4-13
Service Compartment	4-5g	4-3
Travel Aids		7-1
Troubleshooting:		
Refrigerator	5-1c(2)	5-9
Toilet	5-3c(4)	5-15
Tune-Up	4-28	4-36
Turn Signal:		
Indicators	4-9h	4-7
Lever	4-9s	4-9
Turn Signal/Park Light	4-19c	4-15
Turning	7-3j	7-9

U

Upgrade Holding	4-15	4-14
-----------------------	------	------

V

Vanity	5-3a	5-13
Vehicle Leveling Switch	5-6b(7)	5-33
Voltage Gauge	4-9g	4-7

W

W (Continued)

Subject	Para- graph	Page
Warranty:		
Appliance	2-3	2-2
Certificate	2-2c	2-2
FMC	2-1	2-1
Non Warranted	2-5	2-2
Owner's Registration Card .	2-2b	2-2
Registration	2-2	2-1
Service and Repair	2-6	2-3
Subsequent Owner's Registration Card	2-2d	2-2
Supplier	2-4	2-2
Waste Disposal Stations	5-8c	5-47
Waste Destruct Switch	5-6b(9)	5-33
Waste Drainage System.....	5-8	5-46
Waste Water and Sewage Tank Drain Compartment	4-5d	4-3
Water Level Switch	5-6b(3)	5-32

Subject	Para- graph	Page
Water Pump, Domestic:		
Maintenance	5-5e(1)	5-27
Operation	5-5b(2)	5-23
Switch	5-6b(8)	5-33
Water Tanks, Domestic	5-5b(1)	5-23
Water Temperature Gauge	4-9f	4-6
Weights.....	6-2	6-1
Wheel Alignment	4-24f	4-26
Wheels and Tires (Also See Specific Item Entry).....	4-24	4-23
Windows:		
Driver/Passenger.....	4-9w	4-9
Rear Compartment.....	5-2g	5-13
Windshield Washer Compart- ment	4-5b	4-3
Wiper/Washer Control Switches	4-9l	4-7